



# CONNECTING FENAC ETHERNET/IP ENCODER TO CODESYS ENVIRONMENT

Power cable and data cable are correctly connected to the device. Details about the connection pinout structure are explained in the section "[4.Connector & Pin Assignment](#)". Power cable and data cable are indicated in the figure on the side. It is also specified to which input ports the power cable and data cable will be connected to the Fenac Ethernet IP encoder. The device can be supplied with DC voltage in the range of 10V to 30V. The other end of the data cable must be connected to an Ethernet IP master. Here we will talk about two methods. Defining a personal computer as an ethernet IP master device and connect the data cable to the ethernet port of a PC is an easy method, as no external hardware is required. You can do your various tests in this way. The other method is to use a PLC device with Ethernet IP Master as traditionally.



# HARDWARE INSTALLATION

In order to connect the Fenac Ethernet IP encoder and make its adjustments, a connection must be made as shown in the figure.



# PING TEST

Before going into any stage first we should make sure our encoder hardware device connected successfully and we are in the same ip node. You should ping the encoder device if every connection made successfully.

```
C:\Users\ >ping 192.168.2.101

Pinging 192.168.2.101 with 32 bytes of data:
Reply from 192.168.2.101: bytes=32 time=2ms TTL=255
Reply from 192.168.2.101: bytes=32 time=1ms TTL=255
Reply from 192.168.2.101: bytes=32 time<1ms TTL=255
Reply from 192.168.2.101: bytes=32 time=1ms TTL=255

Ping statistics for 192.168.2.101:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 2ms, Average = 1ms
```

If you can see the following output then you are in the same ip subnet and your encoder connected successfully. Else you get “Request timed out” message then you should fix you connection.


```
C:\Users\ >ping 192.168.2.101

Pinging 192.168.2.101 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.


Ping statistics for 192.168.2.101:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
```

# IP SETTINGS

You can set your **PC's IP subnet** in the following picture.



And you can follow the below steps to set your **PLC's IP subnet**.



```
C:\Users\>ping 192.168.2.100

Pinging 192.168.2.100 with 32 bytes of data:
Reply from 192.168.2.100: bytes=32 time=2ms TTL=64







Ping statistics for 192.168.2.100:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 2ms, Maximum = 2ms, Average = 2ms
```




After that as you can see here you should ping the PLC's IP Address(192.168.2.100) too.

# CODESYS SETTINGS

Legend:

- single left click
- D → double left click
- R → right





Finally under the Device tab click on PLC Settings and configure below settings.

Window Help

LOGIN BUTTON

Device FNC\_AEIPM\_ETHERNETIP\_ENCODER\_1 x

General

Connections

Assemblies

User-Defined Parameters

EtherNet/IP I/O Mapping

EtherNet/IP IEC Objects

Status

Information

Connection Name	RPI (ms)	O->T size (bytes)	T->O size (bytes)	Proxy Config size (bytes)	Target Config size (bytes)	Connection Path
1. Exclusive Owner	10	8	16		28	20 04 24 66 2C 64 2C 65

Add Connection... Delete Connection Edit Connection...

Configuration Data

Raw data values Defaults

Parameters	Value	Unit	Datatype	Minimum	Maximum	Default	Help String
Exclusive Owner							
Target Config data							
SingleTurn	360	counts	UDINT	1	16#40000	16#40000	Number of requestet steps per turn, counts per
TotalRange	360	counts	UDINT	1	16#40000000	16#40000000	Total number of steps
Preset_Parameter	0		UDINT	0	16#40000000	0	
preset_changed	1		UDINT	0	16#40000000	0	
Store_Parameters	0		UDINT	0	16#40000000	0	0x65766173 The signature that shall be written i
Restore_Parameters	0		UDINT	0	16#40000000	0	0x64616F6C The signature that shall be written
Operating_Parameter	4		UINT	0	16#4000	0	
Unused Parameter	0		BYTE	Bit 0	Bit 7	0	
Unused Parameter	0		BYTE	Bit 0	Bit 7	0	

You can configure the parameters like “SingleTurn” ,“TotalRange” , “Preset\_Parameter” , “preset\_changed” and “Operating\_Parameter” here in this Connection page. After that you should click on “Login” button to set this parameters. Then start button to start operations.

Device FNC\_AEIPM\_ETHERNETIP\_ENCODER\_1 x

General

Connections

Assemblies

User-Defined Parameters

EtherNet/IP I/O Mapping

EtherNet/IP IEC Objects

Status

Information


Find Filter Show all

Varia...	Channel	Address	Type	Current Value	Description
	Fault Header	%ID0	DWORD	0	New Help String
	Position Value	%ID1	DINT	156	Current position sensor value (32 bit)
	Velocity Value	%ID2	DINT	0	
	Alarm Flag	%IB12	SINT	0	New Help String
	Warning Flag	%IB13	SINT	0	
	Unused Parameter	%IB14	BYTE	0	
	Unused Parameter	%IB15	BYTE	0	
	Consumed Data	%QW0	UINT	0	
	Consumed Data	%QW1	UINT	0	
	Consumed Data	%QW2	UINT	0	
	Consumed Data	%QW3	UINT	0	

Here in this Ethernet/IP I/O Mapping page you can see the process datas like Position Value and Velocity value.

## 4. Connector & Pin Assignment

### Pin Assignment



PIN	Signal
1	U <sub>s</sub> 10 V...30V
2	Not assigned
3	GND
4	Not assigned

PIN	Signal
1	T x D+
2	R x D+
3	T x D-
4	R x D-

#### Counter Connector Part Number

**FCSF M1204** : M1204 Female Connector  
**FCSF M1204 R200** : M1204 Female Connector with 2 meter cable



#### Counter Connector Part Number

**FCSM DTM1204** : D Type M1204 Female Connector  
**FCSM DTM1204 R200** : D Type M1204 Female Connector with 2 meter cable

